

MMCX set installation

Notes:

1. SF3X6, SF3X5, SB3X8, SH0.5, SH1.75, ST019, ST55, ST105, ST110 are not included.
2. Use AT55M Spur Nut instead of AT55.
3. Pay attention on the recommended position of the AT67 washer on the left side of the pulley.
4. Front belt should be on the left side and the rear belt - on the right side. So alter orientation of the spool and the diff according to this opposite layout of belts.

