

# MX Tran-01 Manual

Thank you for choosing the MXO-RACING products, please read this document carefully before using it!

MX Tran-01 is an ultra-small-volume infrared transponder, which is suitable for the EasyLAP system.

## Features:



- Ultra -small volume: 7.5\*6.0\*2.9mm;
- Work voltage: 3.3 ~ 8.5V;
- Personal ID number is programmable;
- Personal ID range: 1 ~ 16777215;
- Easy to install;
- Universal.

## Power supply connector connection:




The working voltage of MX Trans-01 is 3.3 ~ 8.5V, so the power connector of MX Trans-01 can be connected to the servo interface of RXC42-X or on the communication port of the miniz, as shown in the figure below

**The power connector of MX Trans-01 is connected to the servo interface (1.5mm 3P) of RXC42-X:**



**The power connector of MX Trans-01 is connected to the servo interface (1.5mm 3P) of RXC42-X:**





## Working Mode:



MX Trans-01 has two ID modes: 1) Random ID mode; 2) user ID mode.

MX Tran-01 works in random ID mode while manufacturing. In this mode, the ID is determined by the UUID of the internal MCU of the product. Users or dealers can also change the MX Tran-01 to the user ID mode, which is customized by the user in this mode.



## How to set up a Personal ID:



Please refer to the "MX Transponder Personal ID Setting Method" document.

## Contact us



Please contact us if you have any feedback or suggestions, thank you!

Web: [www.mxo-rc.com](http://www.mxo-rc.com)

Email: [info@crossover-rx.com](mailto:info@crossover-rx.com)

[mxo@mxo-rc.com](mailto:mxo@mxo-rc.com)

